

PRE-START CHECKLIST

- Fill the fuel tank, using clean fuel
- Check the fuel supply for contaminants such as water, dirt or algae
- Drain the water from the fuel/water separator
- Check that there is fuel in the fuel line, if necessary prime the fuel line
- Check the engine oil level
- Check coolant level
- Check the indicator button for the battery charge
- Check the oil level in the pump's mechanical seal oil reservoir
- Make sure that the fan/alternator drive belt is tight
- Make sure that the safety guard surrounding the torsional damper is secure and in place
- Check that suction and discharge connections are tight and secure
- Make sure that the pump is level